
DBM-1 Flat Key Machine



Instruction Manual & Parts Book




NEW AREA CODE (989)

(517) 354-5623


Framon Manufacturing Co., Inc. 909 Washington Ave., Alpena, MI 49707 e-mail: framon@northland.lib.mi.us

CUTTING PROCEDURE FOR FRAMON DBM-1 FLAT KE' MACHINE




Al keys should be set from the tip for spacing

on blank if blank tip is slightly different than pattern key. protruding slightly beyond left side of vise (Fig #1). The In this position tip can be cut without cutting vise reason for this position is to allow culting of tip guide Insert pattern key in right hand vise with tip of blank




Push guide shaft rearward and lock nto this position by tightening locking kncb (Fig. #2). This relieves spring pressure so tip setting is easier. Lift yoke and set tip of pattern key against right hand side of guide. While holding this position, insert blank and set tip of blank against right hand side of cutter (Fig. #3). This procedure assures proper spacing.



Release guide by loosening locking knob and key is ready to be cut.

Set cut in pattern key against guide and lift yoke into cutter to make cut (Fig. #4), lower yoke and repeat for next cut. Follow this procedure until all cuts (including throat cut) are made and key is complete. All cuts should be made with a straight in motion. This will insure clean square cuts

You will notice there is no side play in guide assembly so all cuts on duplicate key will be the same width as pattern key.



MAINTENANCE

Yoke rod (DCSH107), guide shaft (DBSH112) and vise studs (F2SC003) should be lubricated using very fine oil sparingly (do not use motor oil).

Be sure to wipe cff all excess oil. To lubricate guide shaft (DBSH-112), unscrew locking knob (DBMS052) and put one or two drops of oil in opening and replace knob.

Other than these parts, cleanliness is the best maintenance.


<u>CAUTION</u>: Cutter on the DBM-1 is solid carbide. Do not use excessive side pressure. There is always the possibility of breakage when side pressure is applied. <u>Always use protective</u>

WARRANTEE

The warrantee on the Framon DBM-1 is in effect or a period of one year from date of purchase. Framon Mtg. Co. will replace all or any part of any machine proven to be defective as to material or workmanship. If any machine is returned to us in the first year, Framon Mfg. will absorb all cost for repairs, including freight. After one year, Framon Mfg. will charge customer for parts, a flat labor rate, and freight. Machines will be repaired and returned within two days of receipt. This warrantee is valid to the original purchaser only. Cuters are not converted by this warrantee. Framon cutters are among the finest cutters made today, but we have no control over their use.

WARRANTEE CLAIMS PROCEDURE

Purchaser must inform Framon Mfg. by telephone or letter and obtain permission from Framon before returning any machine. Framon will not accept any machine returned without prior permission. Any correspondence pertaining to any problem with a Framon machine should include date of purchase, from whom purchased and serial number of machine.



1/8 Allen Wrench

5/16 Allen Wrench

Instruction and Parts Manual

ADJUSTMENTS

With tip setting for spacing there is no adjustment needed for spacing.

As to depth settings, this can be checked by using two blanks that are the same and check depth by drawing blank against cutter guide. If depth adjustments are needed, simply loosen set screw on depth ring and adjust ring until cutter barely touches blank. To make cuts deeper, rotate depth ring counter clockwise. To make cuts shallower, rotate depth ring clockwise.

Tighten set screw after adjustment is made but do not over-tighten.

Another way to check depth is to make one cut on duplicate key and check depth cut on both pattern key and duplicate key. As an example, if cut on duplicate key is .003 deeper than cut on pattern key, loosen set screw on depth ring, rotate rng .003 clockwise and tighten set screw. NOTE: Calibrations on depth ring are in increments of .001.

Check guice setting - guide must be set to same width of cutter used. The DBM-1 is supplied with one .045 width cutter. This is the best width for general work. Cutter widths of .035, .055, .066 and .088 are available if needed. Cutter width of .100 (LeFebure) can be obtained by using an .045 and an .055 at the same time. All of these cutters are solid carbide.

To set guide, simply loosen cap screw (DBSC003). Rotate guide to cutter width and tighten cap screw. Detent screw in guide shaft will align guide. No adjustment is required when changing guide settings.

PARTS LIST

F2MT002 F2MT003 F2MT004 F2MT008 F2MT009 F2SH014 F2SH035 GHMS601	2 - 2 - 2 - 2 - 2 - 2 - 2 - 2 - 2 - 2 -	BSH1 BSH1 BSH1 BSH1 BSH1 CMS2 CMS2 CMS2 CMS2 CMS2 CMS4 CMS6 CMS6 CMS6 CMS6 CMS7 CSH1	DBC1045 DBMS001 DBMS051 DBMS201
Motor 3 Wire Cord 3/8 Pulley Toggle Switch On/Off Plate Vise Clamp Nut Spacing Washer O Ring Belt		e Block Plate e Shaft e e Shaft Hax Key Hax Key ZE Buntir d 2 Pulley Wiper Bar Bar Fod	Carbide Cutter Spring Yoke Knob Pulley Washer